Introduction to the IDE

1 Introduction

The IDE that we are using is called SourceBoost, and is available on all of the machines in the ELC. There is also a free version which has some limitations that you can download and run on your personal computer.

The steps in programming a microcontroller using the IDE are as follows:

1.1 Start the Software

Starting the software is done like any standard windows software.

1.2 Create or Open a Project

SourceBoost uses a "container" called a project to keep all of the details of your program together. These details include the file(s) that the program uses, specifics about the target processor, and other information.

When creating a new project, I would avoid using the wizard until you are more familiar with the IDE and C programming.

1.3 Add files to the project

All files and libraries have to be added to the project. Do not add header files to the project. They are included via the #include statements in your code.

SourceBoost includes an editor that can be used to edit and create programs, but you can use any code editor of you like.

1.4 Compile your project

With all of the files added to the project, it is time to use the \mathbb{C} compiler to compile your project. The bottom half of the screen will show the results of this process.

1.5 Link your project

Once the project has been successfully compiled, the next step is to link the project using \mathfrak{L} . This program, run from inside the IDE, will take the output of the compiler and translate it into a HEX file.

1.6 Program your microcontroller chip

The next step is to program the hex file that was generated by compiler and linker into the microcontroller. The name of the hex file will be the name of your project with the file extension .hex. When the programmer software comes up, you may have to load the appropriate hex file before downloading. This is a separate piece of software, although it

is launched from the IDE. This program sends the hex file to the hardware programmer mentioned above, which writes the program into the memory on the microcontroller.

1.7 See if the program worked

Once the hex file is downloaded, press the reset button on the development board. The program will start from the beginning and run to the end. Note that the program usually will start running without a reset, but that may not always be the case.

2 Detailed Instructions

The following is a cookbook approach to the steps necessary to run the IDE.

- 1. Determine where you are going to keep your code, libraries, etc. This needs to be a directory that you have permissions on, and can be in your AFS space, on a memory stick, etc. This document is an edited version of one used in EE 20222 and it assumes there is a directory called workfolder extant for this purpose.
- 2. Run the SourceBoost IDE. The program can be found in Start \rightarrow All Programs \rightarrow SourceBoost \rightarrow SourceBoost IDE.
- 3. Create a new project in your working directory. To do this, go to the Project menu of the IDE, and select new.

🐄 SourceBoost II	DE
File Edit View	Project Build Settings Plugins Help
D 🗳 🖬 🝘	Quick 🎁 😰 💥 📲
Workspace	New
⊡- <mark>അ</mark> C:\lah224-2	Open
prog.c	Wizard
	Add File(s)
prog.	1 C:\lab224-2005\prog2\progc
E prog.	2 C:\lab224-2005\prog\progc
	3 C:\labdev\I2C test\I2Cc
	4 C:\lab224-2005\\I2Cc
	5 C:\lab224-2005\\countbc
	6 C:\lab224-2005\\oscc
	7 C:\lab224-2005\\spitestc
	8 C:\lab224-2005\\SPIc

This will open up the dialog box shown below. Change the directory to point to some folder and choose a name for your project. (I chose in this example to call mine lab2rms.)

Open			? 🛛
Look jn: 📔	workfolder	• 🗢 🖻) 💣 🎟 -
File <u>n</u> ame:	lab1-RMSc		<u>O</u> pen
Files of type:	Prj Files(*c)	•	Cancel

A new project dialog box will appear. You should choose to create an empty project.

New Project	
Create new project:	ОК
empty with empty source file with empty source and header files	Cancel
Toolsuit: BoostC 🗨	

4. Add your file to your project.



After adding the file, it should show up in the left column.



Notice the workspace display. The project name is listed in bold on the first line. Below it you can see the file that I added to the project.

5. Add the EESDlib.c to the project.



6. Double click on the name of your C file, and it will show up on the right hand part of the screen, where it can be viewed and edited. Note that the editor uses colors to indicate various different types of information in a C program.

😺 SourceBoost IDE - [C:\Pic software\boardtest\testprog.c]							
D File Edit View Project Build	d Settings Plugins Window Help						
D 🚅 🖬 🏉 X 🖻 🖻 🎒) 🔁 🔁 🗿 🗶 1 19 😰 💥 🔚 🔄 🖬 🖷 🕸 🖉 🔕 🖉 🗐						
Workspace * X testprog.c							
Workspace x Workspace x C+Pic software\boardtest EESDIb.c Uutput Itestprog.lst Itestprog.hex	<pre>testrog.c testrog.c /***********************************</pre>						
	<pre>LCD_printf("Test Program"); delay_s(5);</pre>						

7. Note that there are a number of settings under options that should be correctly pre-set for you but with multiple students using each setup, there are no guarantees. The correct setting are as follows:

Settings -> Toolsuit

Active Toolsuit Selection	X
Active Toolsuit:	ОК
BoostC	Cancel

Settings -> Target



Settings -> Options -> tools

BoostC compiler options	×
Compile Options Tools Debugger	
Compiler&Linker directory:	
C:\Program Files\SourceBoost\	
Programmer: "C:\Program Files\melabs Programmer\meProg.exe"	
<u>G</u> et Default	
<u>S</u> et Default] [

Note that the specific location of the programmer software may be different than what is shown because of the installation setup in the IDE.

In the programmer line of the above box, the complete text is

"C:\Program Files\melabs Programmer\meProg.exe" -D%target% -X

The –D%target% tells the programmer the target processor (so you don't have to specify it there again) and the –X tells the programmer to close when it has completed programming. The quote marks are required if you plan on having the programmer launched as part of the build command.

Settings -> Build

Set the options you want to happen when you click on build \mathfrak{B} . If you include program, it will automatically launch the programmer software.



8. Compile your project. Simply click on the gothic € in the top toolbar. In the bottom window, you will see the output from the compile, and if you entered the program correctly you should see no errors. (Note that there will be a number of warnings! These can be safely ignored.) If there are errors, you can double click on the error and it should take you to the offending line. (Note that it is not always

possible for the compiler to figure out exactly where the error is, but it should be close to the line given.)

- 9. Link your project. Click on the gothic \mathfrak{A} , and the linker will link the project. (Note that if you had the build options as shown above, clicking on the gothic \mathfrak{B} would have done both these steps.)
- 10. Compiling and linking produces three output files. An assembly file (.asm), a list file (.lst) and a file that can be downloaded to the microcontroller (.hex).

Download the hex file to the microcontroller board. Click on the gothic 3 and the programmer will start and will appear as below. Note the window that says target. This has to be set as shown. Once it is set, it should remain so.

% meProg - mothertest.hex	
<u> F</u> ile <u>V</u> iew <u>P</u> rogram <u>O</u> ptions <u>H</u> elp	
🗠 🖬 🖄 🗸 🗇 💡 🚀 🛛 PIC18F4620	▼ C M

You can also view the configuration bits and the code (C and M buttons), which look like this:

🚸 meProg - Configuration	- 🗆 🗙
Oscillator	HS 🔽 🔺
Fail-Safe Clock Monitor	Enabled 💌
Internal External Switch Over	Enabled 🗾
Power-up Timer	Disabled
Brown-out Reset	Enabled, SBOREN Disabled
Brown-out Reset Voltage	2.0V 💌
Watchdog Timer	Disabled
Watchdog Timer Postscaler	1:32768
CCP2 Multiplexed with	RC1 V

🏇 meP	rog - m	othert	est.hex	¢					
Code EEPROM Data User ID Configuration Device ID									
60009- 6010- 6020- 6030- 6040- 6050- 6050- 6050- 6080- 6080- 6090- 6080- 6080- 6080- 6080-	ef54 0000 d7ed ec02 ec02 5009 908d 948d 1007 90d8 3608 0e0f	f 002 0000 0012 f 000 f 000 6ead 828d 5083 6e8c 3607 90d8 148c	521d 0000 0efa 2e03 0012 928d 6e06 908d 3608 3608 3607 1009	0000 0000 0000 6e1d 6e1d d7ee 948d 0e01 0ef0 828d 90d8 3608 6e8c	e101 0000 ec02 ec02 0012 0e0f 6e1d 1405 928d 3607 0ef0 908d	0012 0fff 0000 f000 848d 148c ec02 6e07 5005 3608 1407 828d	0ef9 a4d8 0000 0efa a89e 1003 f000 0e0f 6e07 90d8 6e09 928d	0000 d7f7 2e1d 6e1d d7fe 6e8c 0012 148c 6a08 3607 6a0a 0e03	
00d 0- 00e 0- 00f 0- 0100- 0110- 0120- 0130- 0140- 0xCD76	6005 6e1d 141c 928d 361d 0ef0 808d 5003	d005 ec02 6e1d 501c 361e 141d 828d 6eaf	0e14 f000 0e0f 6e1d 90d8 6e1f 928d 5004	6e1d 5006 148c 6a1e 361d 6a20 0e01 6eb0	ec 02 6e83 101d 90d8 361e 0e0f 6e1d 0e24	f000 0012 6e8c 361d 90d8 148c ec02 6eac	d004 948d 808d 361e 361d 101f f000 0e90	0e01 0ef0 828d 90d8 361e 6e8c 0012 6eab	•

There are a number of options that can be set under the options menu item. The main toolbar items are as indicated below:



Note that the device does not need to be erased before programming.

When you click on the program button, the programmer will download the hex file into the microcontroller with dialog boxes indicating progress, and then the code should begin to execute. It you specified the -X in the command line, the programmer will automatically close.

11. If the program doesn't automatically start running on the microcontroller board, press the reset button on the microcontroller board.